



DFW Deluxe Food Warmer

Steaming Guide

With just plain tap water, the Deluxe Food Warmer can quickly prepare a variety of foods. Use the suggested cooking times listed below on noodles, rice, cereals, breads, meat, seafood, poultry, eggs, and vegetables. Or experiment with your own products and steaming times. A little more or a little less steam could enhance the appearance and flavor.

Product Description	Cook Time	Product Description	Cook Time
Macaroni	5 minutes	Clams	single shot of steam
Spaghetti	5 minutes	Lobster Tails	16 minutes
Rice	20 minutes	Scallops	5-8 minutes
Oatmeal	6 minutes	Shrimp	5-6 minutes
Bagels	3 minutes	Chicken	23-25 minutes
Rolls	single shot of steam	Scrambled Eggs	5 minutes
Buns	single shot of steam	Asparagus	11-14 minutes
Tortilla	single shot of steam	Broccoli	12-14 minutes
Bratwurst	10 minutes	Carrots	12 minutes
Hamburgers	10 minutes	Corn	4 minutes
Ribs	10 minutes	Green Beans	10 minutes
Sausage	8-10 minutes	Peas	8 minutes
Crab Legs	4-5 minutes	Mashed Potatoes	8 minutes

